



Lotus Europa S1 Parts Manual - Section F3 - Transmission - Bell Housing - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
46F6020	46F6020	1	1									Bell Housing - Replaced by A046F6020	
8023100309	8023100309	2	2									Bolt 10 x 35	
8023080259	8023080259	2	2									Bolt 8 x 25	
1081200669	1081200669	8	8									Spring Washer	
1081110859	1081110859	8	8									Washer	
46F6021	46F6021	1	1									Seal Carrier	
46F6022	46F6022	1	1									Seal (697-04)	
46F6023	46F6023	2	2									Bushing	
1081201069	1081201069	4	4									Spring Washer	
8023100406	8023100406	2	2									Bolt 10 x 45	
1081111059	1081111059	4	4									Washer	
8023080306	8023080306	6	6									Bolt 8 x 30	
46F6024	46F6024	2	2									Bushing - Cross Shaft	