



Lotus Europa S1/S2 Parts Manual - Section EP - Engine - Water Pump - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
1	046E6297	1	1									Water Pump Assembly replaced by A054E6058 after exhausting old stocks	
1	A046E6297	1	1	1								Water Pump Assembly replaced by A054E6058 after exhausting old stocks	
1	A054E6058	1	1	1	1							Water Pump Assembly	
2	046E6296	1	1	1	1							Connector - Hose to Throttle Block	(697-04) to Eng. No. 1790 - (821-30) to Eng. No. 0411
2	A054E6069	1	1	1	1							Connector - Hose to Throttle Block	(697-04) From Eng. No. 1790 - (821-30) from Eng. No. 0412
3	046E6294	1	1	1	1							Intermediate Plate	
4	046E6295	1	1	1	1							Water Pump to Intermediate Plate Gasket	
5	046E6292	1	1	1	1							Water Pump Intermediate Plate to Cylinder Block Gasket	
6	A046W6043	4	4	4	4							Bolt - 7 x 60	
6	A046W6047	4	4	4	4							Washer	
7	A046W6044	3	3	3	3							Bolt - 7 x 40	
7	A046W6047	3	3	3	3							Washer	
8	A046W6041	2	2	2	2							Bolt 7 x 35	(697-04) to Eng. No. 1641 - (821-30) to Eng. No. 0222
8	A046W6042	2	2	2	2							Bolt 7 x 20	(697-04) from Eng. No. 1642 - (821-30) from Eng. No. 0223
8	A046W6047	2	2	2	2							Washer	(697-04) from Eng. No. 1642 - (821-30) from Eng. No. 0223
9	046E6293	2	2	2	2							Bolt - 7 x 55	(697-04) to Eng. No. 1641 - (821-30) to Eng. No. 0222
10	A046W6042	2	2	2	2							Bolt - 7 x 20	(697-04) from Eng. No. 1642 - (821-30) from Eng. No. 0223
10	A046W6047	2	2	2	2							Washer	(697-04) from Eng. No. 1642 - (821-30) from Eng. No. 0223
11	A046W6046	4	4	4	4							Nut	(697-04) to Eng. No. 1641 - (821-30) to Eng. No. 0222
11	A046W6045	4	4	4	4							Washer	(697-04) to Eng. No. 1641 - (821-30) to Eng. No. 0222