



Lotus Europa S1/S2 Parts Manual - Section ER - Engine - Fuel Pump - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
1	A054E6075	1	1	1	1							Fuel pump - replaced by A065E6000	
1	A065E6000	1	1	1	1							Fuel pump	From Chassis No. 2520 and 1178
2	046E6320	1	1	1								Housing - lower (697-04)	
2	A054E6076				1							Housing - lower (821-30)	
3	046E6329	1	1	1								Housing - upper (697-04)	
3	A054E6078				1							Housing - upper (821-30)	
4	046E6319	1	1	1								Lever Assembly - with spring (697-04)	
4	A054E6080				1							Lever Assembly - with spring (821-30)	
5	046E6314	1	1	1								Repair Kit (697-04)	
5	A05E6081				1							Repair Kit (821-30)	
6	046E6315	1	1	1								Diaphragm (697-04)	
6	A054E6083				1							Diaphragm (821-30)	
7	046E6325	1	1	1	1							Fuel Pump Filter Bowl Gasket	
8	046E6331	1	1	1	1							Fuel Pump Housing to Valve Assembly Gasket	
9	046E6332	1	1	1	1							Valve Assembly	
10	046E6316	1	1									Spring - diaphragm (697-04)	
11	046E6317	1	1	1								Washer - diaphragm spring (697-04)	
11	A054E6087				1							Washer - diaphragm spring (821-30)	
12	046E6318	1	1	1								Washer - diaphragm spring seat (697-04)	
12	054E6086				1							Washer - diaphragm spring seat (821-30)	
13	046E6324	1	1	1	1							Cover	
14	046E6327	1	1	1	1							Filter	
15	046E6326	1	1	1	1							Spring - fuel filter	
16	046E6328	8	8	8	8							Screw - upper housing to lower housing	
17	046E6328	2	2	2	2							Screw - valve assembly to upper housing	
18	046E6323	1	1	1	1							Clamp - filter cover	
19	046E6322	1	1	1	1							Screw - filter cover	
20	046E6330	1	1	1	1							Screw - lever to housing	