


EJ



Lotus Europa TC/TCS Parts Manual - Section EJ - Engine - Airbox - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
1	A094S0186Z					1		1		+	+	Backplate - airbox	
2	A026S0016Z					1		1		+	+	Airbox Gasket	
3	A074S0187Z					1		1		+	+	Airbox	
3	16					3		3		+	+	Bolt - Airbox Securing	
3	116					3		3		+	+	Washer - Shakeproof - Airbox Securing	
4	A074S0112S						1	1				Assembly - Airbox	
4	18A						6	6				Bolt - Assembly - Airbox	
4	116						6	6				Washer - Shakeproof - Assembly - Airbox	
4	118						6	6				Washer - Plain - Assembly - Airbox	
5	A026E0322A					1	2	1	2	+	+	Gromet - Breather Tube	
6	X026S0052Z					1		1		+	+	Tube - Breather	
7	X026S0054Z					1		1		+	+	Hose - Breather	
8	X036S6020Z					2		2		+	+	Clip - Hose	
9	Z026S0052Z						1	1				Tube - Breather	
10	X036S6006Z					2	2	2	2			Clip - Airbox Hose	
11	A074E0467Z					1	1	1	1			Airbox Hose (3 1/2 ins x 6 ins)	
12	B026S0704W					1	1	1	1			Assembly - Air Cleaner	
13	X036S6007Z					2	2	2	2			Ring - Sealing - Air Cleaner	
14	X028S0020Z					1	1	1	1			Air Filter Element	
14	B074E0196Z					1	1	1	1			Bracket - Air Cleaner to Luggage Compartment	